## Kit17 - ES Lampholder

For further information visit: help.marginservices.co.uk Search for IS17ES in the search box. Ref:

IS-17ES

Plastic

Plastic

Steel Nut

## **Kit Contains:**

1x Cable Cord Set
 1x Steel Nut
 1x Steel Washer
 1x Pottery Nipple
 1x Grommet
 1x Plastic Washer
 1x 40mm Rod

1x Brass Washer

Before you start please ensure you are competent to carry out electrical works and ensure the electricity is turned off.

If in any doubt stop what you're doing and seek professional advice.

Metal Washer

Inside Lamp base Lamp base


We have 2 methods of fixings within this kit, 1 is the pottery nipple (for thin wall ceramic items) and the other is for thicker style ceramic items using a 40mm threaded rod.

**Step 1 (Pottery Nipple):** Take the pottery nipple and place the steel washer followed by the plastic washer over the thread, then push the pottery nipple up through your light fitting so the thread is sticking out the top.

**Step 1 (Threaded Rod):** Take the threaded rod and screw the nut on the bottom and push in the tube grommet into the end of the rod.

Outside Lamp base

Place the steel washer then plastic washer place over the thread, then push the assembly up through your light fitting so the thread is sticking out the top.



**Note:** You may need to cut/adjust the thread if too long. Approx. 6mm is required to go into the lampholder.



**Step 3:** Take the strain relief and push the cable through one hole then back through the other, Then pass the cable through the ceramic base and out the top of the bottom section of the lampholder.



**Step 4 ES lampholder:** Take the plastic connection unit and wire it as the drawing below, ensuring the correct wire is in the correct connection, Note there are L and N marking on the connection unit.

N = Neutral—Blue | L = Live—Brown

**Step 5:** Once the connection unit has been wire carefully push it into the base of the lampholder ensuring no cables are trapped.



**Step 6:** Take the top section of the lampholder and screw it over the top noting a clicking noise as you tighten it up.

The clicking noise is the locking barb which is a safety feature of all E27 lampholders, this ensures that the skirt (top section) does not come away form the bottom section when unscrewing a light bulb.

For further information visit: help.marginservices.co.uk and search for "unlocking"

If you have any concerns or difficulties in connecting this product please contact us, details at the bottom of this guide.

All electrical parts confirm to BS standards and have full CE approval, please email for copies.





Unit 3 Brookside Business Park | Brookside Avenue | Rustington | West Sussex | BN16 3LP

T: 01903 776644 | KB: help.marginservices.co.uk

© Lampspares. All Rights Reserved

Rev: 01-A - 16/05/2024